AUCH
COMMERCIAL



FXC-16C Commercial Cold Water Carpet Extractor

User Manual

[Revision 1.0]

READ THIS MANUAL CAREFULLY BEFORE USE – FAILURE TO DO SO MAY RESULT IN INJURY, PROPERTY DAMAGE AND MAY VOID WARRANTY. • KEEP THIS MANUAL FOR FUTURE REFERENCE. • Products covered by this manual may vary in appearance, assembly, inclusions, specifications, description, and packaging.

Safety

Safety messages are designed to alert you to possible dangers or hazards that could cause death, injury or equipment or property damage if not understood or followed. Safety messages have the following symbols:



You WILL be KILLED or SERIOUSLY INJURED if you do not follow instructions.



You CAN be KILLED or SERIOUSLY INJURED if you do not follow instructions.



You CAN be INJURED if you do not follow instructions or equipment damage may occur.

It is vital that you read and understand this user manual before using the product, including safety warnings, and any assembly and operating instructions. Keep the manual for future reference.

Safety precautions and recommendations detailed here must be fully understood and followed to reduce the risk of injury, fire, explosion, electrical hazard, and/or property damage.

Safety information presented here is generic in nature – some advice may not be applicable to every product. The term "equipment" refers to the product, be it electrical mains powered, battery powered or combustion engine powered.

- **Before Use** - If you are not familiar with the safe operation/handling of the equipment or are in any way unsure of any aspect of suitability or correct use for your application, you should complete training conducted by a person or organization qualified in safe use and operation of this equipment, including fuel/electrical handling and safety.
- Do NOT operate the equipment in flammable or explosive environments, such as in the presence of flammable liquids, gases, or dust. The equipment may create sparks or heat that may ignite flammable substances.
- Keep clear of moving parts.
- Equipment may be a potential source of electric shock or injury if misused.
- Do NOT operate the equipment if it is damaged, malfunctioning or is in an excessively worn state.
- Do NOT allow others to use the equipment unless they have read this manual and are adequately trained.
- Keep packaging away from children - risk of suffocation! Operators must use the equipment correctly. When using the equipment, consider conditions and pay due care to persons and property.

General Work Area Safety

- Work areas should be clean and well it.
- Do not operate the equipment if bystanders, animals etc are within operating range of the equipment or the general work area.
- If devices are provided for connecting dust extraction / collection facilities, ensure these are connected and used properly. Dust collection can reduce dust-related hazards.

General Personal Safety

- Wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect from eye and ear injury, poisoning, burns, cutting and crush injuries. Protective equipment such as safety goggles, respirators, non-slip safety footwear, hard hat, hearing protection etc should be used for appropriate equipment / conditions. Other people nearby should also wear appropriate personal protective equipment. Do not wear loose clothing or jewellery, which can be caught in moving parts. Keep hair and clothing away from the equipment.
- Stay alert and use common sense when operating the equipment. Do not over-reach. Always maintain secure footing and balance.
- Do not use the equipment if tired or under the influence of drugs, alcohol, or medication.
- This equipment is not intended for use by persons with reduced physical, sensory, or mental capabilities.

General Fuel Safety

- Petrol/fuel/gasoline is extremely flammable – keep clear of naked flames or other ignition sources.
- Do not spill fuel. If you spill fuel, wipe it off the equipment immediately – if fuel gets on your clothing, change clothing.
- Do NOT smoke near fuel or when refuelling.
- Always shut off the engine before refuelling.
- Do NOT refuel a hot engine.
- Open the fuel cap carefully to allow any pressure build-up in the tank to release slowly.
- Always refuel in well-ventilated areas.
- Always check for fuel leakage. If fuel leakage is found, do not start, or run the engine until all leaks are fixed.

General Carbon-Monoxide Safety

- Using a combustion engine indoors **CAN KILL IN MINUTES**. Engine exhaust contains carbon-monoxide – a poison you cannot smell or see.
- Use combustion engines OUTSIDE only, and far away from windows, doors, and vents.

General Equipment Use and Care

- Keep packaging away from children and pets, potential risk of suffocation or choking.
- The equipment is designed for domestic use only.
- Handle the equipment safely and carefully.
- Before use, inspect the equipment for misalignment or binding of moving parts, loose components, damage, or any other condition that may affect its operation. If damaged, have the equipment repaired by an authorised service centre or technician before use.
- Prevent unintentional starting of the equipment - ensure equipment and power switches are in the OFF position before connecting or moving equipment. Do not carry equipment with hands or fingers touching any controls. Remove any tools or other items that are not a part of the equipment from it before starting or switching on.
- Do not force the equipment. Use the correct equipment for your application. Equipment will perform better and be safer when used within its design and usage parameters.
- Use the equipment and accessories etc. in accordance with these instructions, considering working conditions and the work to be performed. Using the equipment for operations different from those intended could result in hazardous situations.
- Always keep equipment components (engines, hoses, handles, controls, frames, housings, guards etc) and accessories (cutting tools, nozzles, bits etc) properly maintained. Keep the equipment clean and, where applicable, properly lubricated.
- Store the equipment out of reach of children or untrained persons. To avoid burns or fire hazards, let the equipment cool completely before transporting or storing. Never place or store the equipment near flammable materials, combustible gases, or liquids etc.
- The equipment is not weather-proof, and should not be stored in direct sunlight, at high ambient temperatures or locations that are damp or humid.
- Do not clean equipment with solvents, flammable liquids, or harsh abrasives.
- For specific equipment safety use and care, see Equipment Safety.

© Auch

General Electrical Safety

- Inspect electrical equipment, extension cords, power bars, and electrical fittings for damage or wear before each use. Repair or replace damaged equipment immediately.
- Ensure all power sources conform to equipment voltage requirements and are disconnected before connecting or disconnecting equipment.
- When wiring electrically powered equipment, follow all electrical and safety codes.
- Always use a Residual Current Device (RCD) (GFCI) / Earth Leakage Circuit Breaker / Safety Switch when operating this item (electrical items only).
- High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal.

General Electrical Safety

- Electrically grounded equipment must have an approved cord and plug and be connected to a grounded electrical outlet.
- Do NOT bypass the ON/OFF switch and operate equipment by connecting and disconnecting the electrical cord.
- Do NOT use equipment that has exposed wiring, damaged switches, covers or guards.
- Do NOT use electrical equipment in wet conditions or in damp locations.
- Do NOT use electrical cords to lift, move or carry equipment.
- Do NOT coil or knot electrical cords, and ensure electrical cords are not trip hazards.

General Service Information

- The equipment must be serviced or repaired at authorised service centres by qualified personnel only.
- Replacement parts must be original equipment manufacturer (OEM) to ensure equipment safety is maintained.
- Do NOT attempt any maintenance or repair work not described in this manual.
- After use, the equipment and components may still be hot – allow the equipment to cool and disconnect spark plugs and/or electrical power sources and/or batteries from it before adjusting, changing accessories, or performing repair or maintenance.
- Do NOT adjust while the equipment is running.
- Perform service-related activities in suitable conditions, such as a workshop.
- Replace worn, damaged or missing warning/safety labels immediately.

Child Choking Hazard!



- **WARNING: CHOKING HAZARD - CHILDREN UNDER 8 YRS. CAN CHOKE OR SUFFOCATE ON SMALL PARTS. ADULT SUPERVISION REQUIRED.**
- Carefully inspect anything a baby or child could gain access to, including this product & packaging.
- Dangers include anything of a size that could become stuck or lodged in a baby or child's airway.
- Dangers include things like raw, hard fruit and vegetable pieces, large pieces of meat, bones or sausage skins, popcorn, nuts, hard lollies and corn chips, small magnets and batteries, coins, beads, marbles and small uninflated balloons, broken toys and smaller toys, buttons, keys, and coins. But there are also many more.
- Pay particular attention to accessories, nuts, bolts, screws, washers, caps, covers, loose parts, parts that could be removed or break off, pieces of packaging, staples, tape etc.
- In the case of any doubt, secure the item of concern in an appropriate manner, or completely remove the possibility of access by a baby or child.

Product Safety

- This machine is not intended for use by people with reduced physical, sensory or mental capabilities, or by children, unless they have been given supervision or instruction by a person responsible for their safety.
- Children must be supervised to ensure they do not play with the machine.
- Always unplug the machine from the power outlet before cleaning, servicing or repairing it.
- If the power cord is damaged or loose, it must be replaced by the manufacturer's service department or a qualified technician. The connection must be Type Y.
- Unplug the machine after switching it off.
- **DANGER: READ THIS MANUAL BEFORE OPERATING OR MAINTAINING THE MACHINE. THE OPERATOR MUST RECEIVE HANDS-ON TRAINING BEFORE USING THE MACHINE.**
- **DANGER: DO NOT USE THE MACHINE NEAR FLAMMABLE OR EXPLOSIVE MATERIALS. DO NOT PLACE FLAMMABLE MATERIALS IN THE MACHINE.**
- **DANGER: STOP USING THE MACHINE IMMEDIATELY IF THE POWER CORD IS DAMAGED. TO AVOID ELECTRIC SHOCK, HAVE THE CORD REPLACED BY THE MANUFACTURER OR A QUALIFIED TECHNICIAN.**
- **DANGER: DISCONNECT THE MACHINE FROM THE POWER SUPPLY BEFORE MAINTENANCE OR REPAIRS TO AVOID ELECTRIC SHOCK.**
- **WARNING: IF FOAM OR LIQUID SPILLS FROM THE MACHINE, SWITCH IT OFF IMMEDIATELY, CHECK THE CAUSE AND REPAIR THE FAULT BEFORE FURTHER USE.**
- **WARNING: THIS MACHINE IS HEAVY. DO NOT PLACE, STORE OR OPERATE IT ON SLOPES OR INCLINED SURFACES.**

Safety Symbols

The product may have safety warning labels attached to it, explained below. Understand the symbols on your product and their meanings. If any stickers become unreadable, unattached etc., replace them.



Flammable Material Hazard
Flammable liquids, gases, or substances etc may present. Avoid ignition sources and open flames. Danger of fire.



Read User Manual
Read and fully understand product safety warnings, operation, procedures etc before using the product.



Use Hand Protection
Wear appropriate hand protection and take due care as the product or use of the product may present hand hazards.



Carbon-Monoxide Hazard
Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.



Electrocution / Electrical Shock Hazard
High voltage or high current electricity may be present or required by the product. Take due care when handling electrical products, cables, plugs and leads. Electrical shock can be fatal.



Toxic Fumes / Dust Hazard
Using the product or by-products from use may produce fumes, smoke or particles that could be harmful if inhaled. Wear appropriate breathing protection and have adequate ventilation.



Explosive Material Hazard
Combustible liquids, gases, or substances etc may be present. Avoid ignition sources and open flames. Danger of explosion.



Cutting / Amputation Hazard
The product may have blades, edges or mechanical devices that can cause severe cut injury to fingers, limbs etc. Take due care when handling and using the product.



Crush Hazard
The product may have blades, edges or mechanical devices that can cause severe crush injury to fingers, limbs etc. Take due care when handling and using the product.



Single Operator Only
The product must be operated by a single person only. More than one person operating the product may introduce additional hazards.



Use Face Protection
Wear appropriate full-face protection and take due care as the product or use of the product may present face and eye hazards.



Use Foot Protection
Wear appropriate foot protection and take due care as the product or use of the product may present foot hazards.



Use Eye / Ear / Head Protection
Wear appropriate eye and / or ear and / or head protection and take due care as the product or use of the product may present eye, hearing, and head hazards.



Running Hazard
Do not run on or near the product as doing so may present a fall hazard.



Diving Hazard
Do not dive into the product as doing so may present a neck / head injury hazard.



Adult Supervision Required
Always supervise children and other users of a product to prevent drowning or injury.



Skin Penetration / Puncture Hazard
The product may produce pressure, emit liquids or objects that can cause severe injury to fingers, limbs, blood etc. Take due care when handling and using the product.



Hot Surface Hazard
Be aware that the product may produce high temperatures and hot surfaces that can cause burn injuries.



Flying Debris Hazard
Be aware that the product or use of the product may present hazards produced by flying debris. Wear appropriate clothing and protective devices.



Moving Parts Hazard
Be aware that the product contains or uses mechanical devices that move or rotate. Always wait for moving parts to stop fully before handling the product, adjusting, maintenance etc.

© Auch

 **Carbon-Monoxide Hazard** Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.	 **Pull Hazard** Be aware that the product contains or uses mechanical devices that can pull in objects and can cause severe injury to fingers, limbs etc. Take due care when handling and using the product.	 **Slope / Fall Injury Hazard** Be aware that using the product on sloping surfaces or in slippery conditions may present additional dangers from falls and contact with blades, moving parts, hot surfaces etc.	 **"Slam Dunk" Warning** Do NOT attempt "slam dunk" manoeuvres as this may result in severe injury due to falling, product breakage or collapse etc.
 **Electrocution / Electrical Shock Hazard - Outdoor** High voltage or high current electricity may be present or required by the product. Do NOT use in rain, damp, or wet conditions. Electrical shock can be fatal.	 **Electrocution / Electrical Shock Hazard - Disconnect** High voltage or high current electricity may be present or required by the product. Always disconnect the product from the electrical supply before handling the product, adjusting, maintenance etc.	 **Power Line Electrocution Hazard** High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal.	 **"Kick-Back" Hazard** High level of "kick-back" hazard that can cause the machine to suddenly rotate towards operator. Kick-back injury can be fatal.
 **Winch Operator Position Hazard** Do NOT stand between winch and load. Do NOT use winch to move people.	 **Winch Lift Hazard** Do NOT LIFT load vertically. Use machine to PULL only.	 **Cable Hazard** Ensure that load bearing cable is not kinked or knotted.	 **Winch Cable Hazard** Ensure that there is a minimum number of cable coils on winching mechanism.
 **Winch Hook Hazard** Carry hook to load – do NOT throw or run.	 **Flash / Blinding Hazard** Wear appropriate eye protection for welding. Direct exposure to weld arcs may cause permanent eye injury.	 **Laser Hazard** Laser may be in use – do NOT look directly at laser or allow others to.	 **Choking Hazard** Children under 8 yrs. Can choke or suffocate on small parts. Adult supervision required.


© Auch

Table of Contents

Safety **2**
Safety Symbols 4
Parts Identification **7**
Operation **8**
Operating the Carpet Extractor 8
Clean Water Tank 8
Roller Brush Replacement 9
Brush Height Adjustment 9
Draining the Waste Water Tank 9
Using the Portable Suction Head 10
Maintenance **11**
Daily 11
Cleaning the Float Assembly 11
Cleaning the Filter Screen and Checking for Leaks 11
Roller Brush Troubleshooting 12
Troubleshooting **13**
Specifications **14**

© Auch

Parts Identification




No.	Name	No.	Name
1	Control panel	7	External suction hose fitting
2	Power cable	8	Suction height adjustment handle
3	Wheel	9	Clean water tank
4	Roller brush	10	Clean water tank cover
5	Hand tool suction adaptor	11	Recovery tank
6	Suction head	12	Recovery tank cover

Operation


Operating the Carpet Extractor

1. After unpacking, inspect the machine for damage and check that all accessories are included.
2. Add water and a suitable cleaning detergent to the clean-water tank as required. Add an appropriate amount of defoaming agent to the recovery tank.
3. Connect the machine to a suitable power supply. Press the switches on the control panel and check that each function operates correctly.
4. Move the machine to the carpet to be cleaned and begin cleaning.
5. After cleaning, unplug the machine. Drain the clean-water and recovery tanks, then rinse the recovery tank and suction hose with clean water.



Clean Water Tank

Detergent mixture goes here.




Roller Brush Replacement

1. Switch off and unplug the machine. Wear protective gloves before replacing the roller brush.
2. Push the handle down to tilt the machine until the roller brush is raised off the floor.
3. Pull the roller brush retaining slider towards the front of the machine, then remove the roller brush.




Brush Height Adjustment



Move the height adjustment lever forward or back, according to your needs.

Draining the Waste Water Tank


The unit is equipped with a flexible waste water tube



1. Pull the tube out of its housing.
2. Remove the cap from the top of the tube.
3. Point the tube downward to release the waste water.
4. Continue to do so until all of the waste water has been emptied.

Using the Portable Suction Head

1. Open the rubber cover on the portable suction head adaptor, then connect the suction hose from the portable suction head.
2. Connect the water hose to the corresponding quick-connect fitting beside the suction inlet.



© Auch

Maintenance

Daily

- Keep the machine clean at all times.
- Add approximately 7.5 L of clean water below 50°C to the clean-water tank. Operate the water pump and vacuum system for approximately 1 minute to flush the system and help prevent detergent residue from accumulating.
- Remove dirt and lint from the float assembly in the recovery tank. Ensure the air outlet is clear and unobstructed.
- Check the filter screen at the clean-water tank inlet for dirt or lint and clean it as required.
- At least once a month, flush the system with a solution of 1 part white vinegar to 3 parts water to remove residual alkaline cleaning solution.
- Before storing the machine, drain the tanks and leave the drain valve open.


Cleaning the Float Assembly

- Turn anticlockwise to install.
- Turn clockwise to remove.



Cleaning the Filter Screen and Checking for Leaks

1. Open the cover and clean the filter screen.
2. Replace the sealing ring if the filter leaks.



© Auch

Roller Brush Troubleshooting

If the roller brush does not rotate, check the fuse. If the fuse has blown, replace it with a fuse of the specified type and rating.



Troubleshooting

Problem	Possible Cause	Solution
No power	No power supply	Check that the machine is connected to a working power outlet.
	Circuit breaker has tripped	Check the circuit breaker. Reset it if safe to do so. If the problem persists, contact a qualified electrician.
Power to the motors is intermittent after the switches are turned on	Power cord or internal wiring is damaged	Have the wiring inspected and repaired or replaced by a qualified service technician.
	Switch is damaged	Have the switch repaired or replaced.
	Electrical terminals are loose or making poor contact	Have the terminals inspected and secured by a qualified service technician.
No suction or weak suction	Recovery tank drain valve is open	Close the drain valve.
	Recovery tank lid is not properly sealed	Secure the lid and ensure it forms an airtight seal.
	Suction hose connection is loose	Reconnect and securely tighten the suction hose connection.
	Suction hose is blocked	Clear and rinse the suction hose.
	Float assembly is dirty	Clean the float assembly.
	Suction hose is damaged	Replace the suction hose.
	Vacuum motor mounting is loose	Tighten the mounting screws securely.
Pump motor operates, but no cleaning solution is sprayed	Spray nozzle is blocked	Clean the spray nozzle.
	Filter screen is blocked	Clean the filter screen.
	Solenoid valve is blocked or damaged	Clean, repair or replace the solenoid valve as required.
	Rectifier is damaged	Have the rectifier replaced by a qualified service technician.
	Pump motor is damaged	Have the pump motor repaired or replaced.
	Foreign material is lodged in the pump	Have the pump inspected and cleaned by a qualified service technician.
Roller brush does not rotate	Roller brush drive belt is loose, worn or deformed	Adjust or replace the drive belt.
	Roller brush motor is damaged	Have the motor repaired or replaced.
	Fuse has blown	Replace the fuse with one of the specified type and rating.

© Auch

Specifications

Suitable Carpet Type	Short pile
Power Plug	10A
Power Cord Length	18m
Power (Watts)	2320W
Clean Water Tank	35L
Recovery Tank	35L
Hose Length	4m
Hose Diameter	48mm Outer Diameter / 39mm Inner Diameter
Tank Material	Polyethylene (PE)
Input Voltage	220V
Frequency	50Hz
Vacuum Motor Type	Single-phase AC
Vacuum Motor (Watts	2 x 1000W
Roller Brush Motor	190W
Roller Brush Speed	1400RPM
Roller Brush Width	400mm
Roller Brush Bristles	Nylon
Roller Brush Drive	Belt
Handheld Hose Length	4m
Solution Flow Rate	2L/min
Spray Nozzles	4
Suction	20kPa
Certification	CE

© Auch

Some experts believe that the incorrect or prolonged use of almost any product may cause serious injury or death. To help reduce your risk of serious injury or death, refer to the information below. For more information, see www.datastreamserver.com/safety

- Consult all documentation, packaging, and product labelling before use. Note that some products feature documentation available online. It is recommended to print and retain the documentation.
- Before each use, check the product for loose/broken/damaged/missing parts, wear, or leaks (if applicable). Never use a product with loose/broken/damaged/missing parts, wear, or leaks.
- Products must be inspected and serviced (if applicable) by a qualified technician every 6 months. This is based on average residential use by persons of average size and strength, and on a property of average metropolitan size. Use beyond these recommendations may require more frequent inspections/servicing.
- Ensure that all users of the product have completed a suitable industry recognised training course before being allowed access to the product.
- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or description of application. Be sure to attain third-party approval from a qualified specialist for your application before use, regardless of any assurances from the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (for example, automobile, computer, toaster), there is the possibility of technical issues that may require the repair or replacement of parts, or the product itself. If the possibility of such failure and the associated time it may take to rectify could in any way inconvenience the user, business, or employee, or financially affect the user, business, or employee, then the product is not suitable for your requirements. This product is not intended for use where incorrect operation or a failure of any kind, including but not limited to, a condition requiring product return, replacement, parts replacement, or service by a technician may cause financial loss, loss of employee time or an inconvenience requiring compensation.
- If this product has been purchased in error when considering the information presented here, contact the retailer directly for details of their returns policy, if required.

© Auch. All rights reserved. No part of this document, including descriptive content, concepts, ideas, diagrams, or images may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, scanning, or recording, or any information storage and retrieval system, without express permission or consent from the publisher.