

User Manual

[Revision 4.0]

THE BATTERY MAY HAVE SOME CHARGE ON ARRIVAL, IT IS IMPORTANT HOWEVER THAT THE BATTERY IS CHARGED PRIOR TO USE.

READ THIS MANUAL CAREFULLY BEFORE USE – FAILURE TO DO SO MAY RESULT IN INJURY, PROPERTY DAMAGE AND MAY VOID WARRANTY. • KEEP THIS MANUAL FOR FUTURE REFERENCE. • Products covered by this manual may vary in appearance, assembly, inclusions, specifications, description, and packaging.

Safety

Safety messages are designed to alert you to possible dangers or hazards that could cause death, injury or equipment or property damage if not understood or followed. Safety messages have the following symbols:



You WILL be KILLED or SERIOUSLY INJURED if you do not follow instructions.



You CAN be KILLED or SERIOUSLY INJURED if you do not follow instructions.



You CAN be INJURED if you do not follow instructions or equipment damage may occur.

It is vital that you read and understand this user manual before using the product, including safety warnings, and any assembly and operating instructions. Keep the manual for future reference.

Safety precautions and recommendations detailed here must be fully understood and followed to reduce the risk of injury, fire, explosion, electrical hazard, and/or property damage.

Safety information presented here is generic in nature – some advice may not be applicable to every product. The term "equipment" refers to the product, be it electrical mains powered, battery powered or combustion engine powered.

- **Before Use** - If you are not familiar with the safe operation/handling of the equipment or are in any way unsure of any aspect of suitability or correct use for your application, you should complete training conducted by a person or organization qualified in safe use and operation of this equipment, including fuel/electrical handling and safety.
- Do NOT operate the equipment in flammable or explosive environments, such as in the presence of flammable liquids, gases, or dust. The equipment may create sparks or heat that may ignite flammable substances.
- Keep clear of moving parts.
- Equipment may be a potential source of electric shock or injury if misused.
- Do NOT operate the equipment if it is damaged, malfunctioning or is in an excessively worn state.
- Do NOT allow others to use the equipment unless they have read this manual and are adequately trained.
- Keep packaging away from children - risk of suffocation! Operators must use the equipment correctly. When using the equipment, consider conditions and pay due care to persons and property.

General Work Area Safety

- Work areas should be clean and well it.
- Do not operate the equipment if bystanders, animals etc are within operating range of the equipment or the general work area.
- If devices are provided for connecting dust extraction / collection facilities, ensure these are connected and used properly. Dust collection can reduce dust-related hazards.

General Personal Safety

- Wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect from eye and ear injury, poisoning, burns, cutting and crush injuries. Protective equipment such as safety goggles, respirators, non-slip safety footwear, hard hat, hearing protection etc should be used for appropriate equipment / conditions. Other people nearby should also wear appropriate personal protective equipment. Do not wear loose clothing or jewellery, which can be caught in moving parts. Keep hair and clothing away from the equipment.
- Stay alert and use common sense when operating the equipment. Do not over-reach. Always maintain secure footing and balance.
- Do not use the equipment if tired or under the influence of drugs, alcohol, or medication.
- This equipment is not intended for use by persons with reduced physical, sensory, or mental capabilities.

General Fuel Safety

- Petrol/fuel/gasoline is extremely flammable – keep clear of naked flames or other ignition sources.
- Do not spill fuel. If you spill fuel, wipe it off the equipment immediately – if fuel gets on your clothing, change clothing.
- Do NOT smoke near fuel or when refuelling.
- Always shut off the engine before refuelling.
- Do NOT refuel a hot engine.
- Open the fuel cap carefully to allow any pressure build-up in the tank to release slowly.
- Always refuel in well-ventilated areas.
- Always check for fuel leakage. If fuel leakage is found, do not start, or run the engine until all leaks are fixed.

General Carbon-Monoxide Safety

- Using a combustion engine indoors **CAN KILL IN MINUTES**. Engine exhaust contains carbon-monoxide – a poison you cannot smell or see.
- Use combustion engines OUTSIDE only, and far away from windows, doors, and vents.

General Equipment Use and Care

- Keep packaging away from children and pets, potential risk of suffocation or choking.
- The equipment is designed for domestic use only.
- Handle the equipment safely and carefully.
- Before use, inspect the equipment for misalignment or binding of moving parts, loose components, damage, or any other condition that may affect its operation. If damaged, have the equipment repaired by an authorised service centre or technician before use.
- Prevent unintentional starting of the equipment - ensure equipment and power switches are in the OFF position before connecting or moving equipment. Do not carry equipment with hands or fingers touching any controls. Remove any tools or other items that are not a part of the equipment from it before starting or switching on.
- Do not force the equipment. Use the correct equipment for your application. Equipment will perform better and be safer when used within its design and usage parameters.
- Use the equipment and accessories etc. in accordance with these instructions, considering working conditions and the work to be performed. Using the equipment for operations different from those intended could result in hazardous situations.
- Always keep equipment components (engines, hoses, handles, controls, frames, housings, guards etc) and accessories (cutting tools, nozzles, bits etc) properly maintained. Keep the equipment clean and, where applicable, properly lubricated.
- Store the equipment out of reach of children or untrained persons. To avoid burns or fire hazards, let the equipment cool completely before transporting or storing. Never place or store the equipment near flammable materials, combustible gases, or liquids etc.
- The equipment is not weather-proof, and should not be stored in direct sunlight, at high ambient temperatures or locations that are damp or humid.
- Do not clean equipment with solvents, flammable liquids, or harsh abrasives.
- For specific equipment safety use and care, see Equipment Safety.

© Auch

General Electrical Safety

- Inspect electrical equipment, extension cords, power bars, and electrical fittings for damage or wear before each use. Repair or replace damaged equipment immediately.
- Ensure all power sources conform to equipment voltage requirements and are disconnected before connecting or disconnecting equipment.
- When wiring electrically powered equipment, follow all electrical and safety codes.
- Always use a Residual Current Device (RCD) (GFCI) / Earth Leakage Circuit Breaker / Safety Switch when operating this item (electrical items only).
- High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal.

General Electrical Safety

- Electrically grounded equipment must have an approved cord and plug and be connected to a grounded electrical outlet.
- Do NOT bypass the ON/OFF switch and operate equipment by connecting and disconnecting the electrical cord.
- Do NOT use equipment that has exposed wiring, damaged switches, covers or guards.
- Do NOT use electrical equipment in wet conditions or in damp locations.
- Do NOT use electrical cords to lift, move or carry equipment.
- Do NOT coil or knot electrical cords, and ensure electrical cords are not trip hazards.

General Service Information

- The equipment must be serviced or repaired at authorised service centres by qualified personnel only.
- Replacement parts must be original equipment manufacturer (OEM) to ensure equipment safety is maintained.
- Do NOT attempt any maintenance or repair work not described in this manual.
- After use, the equipment and components may still be hot – allow the equipment to cool and disconnect spark plugs and/or electrical power sources and/or batteries from it before adjusting, changing accessories, or performing repair or maintenance.
- Do NOT adjust while the equipment is running.
- Perform service-related activities in suitable conditions, such as a workshop.
- Replace worn, damaged or missing warning/safety labels immediately.

Child Choking Hazard!



- **WARNING: CHOKING HAZARD - CHILDREN UNDER 8 YRS. CAN CHOKE OR SUFFOCATE ON SMALL PARTS. ADULT SUPERVISION REQUIRED.**
- Carefully inspect anything a baby or child could gain access to, including this product & packaging.
- Dangers include anything of a size that could become stuck or lodged in a baby or child's airway.
- Dangers include things like raw, hard fruit and vegetable pieces, large pieces of meat, bones or sausage skins, popcorn, nuts, hard lollies and corn chips, small magnets and batteries, coins, beads, marbles and small uninflated balloons, broken toys and smaller toys, buttons, keys, and coins. But there are also many more.
- Pay particular attention to accessories, nuts, bolts, screws, washers, caps, covers, loose parts, parts that could be removed or break off, pieces of packaging, staples, tape etc.
- In the case of any doubt, secure the item of concern in an appropriate manner, or completely remove the possibility of access by a baby or child.

Important Safety Information

- Read this user manual carefully first before operating the product.
- Before starting any work, be sure to familiarize yourself with all the design, controls, and functions of the floor scrubber.
- The condition of its parts under normal circumstances and during operation.
- If the floor washing machine is not working properly, the equipment cannot be used.
- The operator must operate this scrubber for the appropriate application (cleaning hard floors).
- When operating, pay attention to obstacles in the workplace, such as stairs, shelves, etc., and pay attention to the surrounding people, especially children.
- Use the appropriate detergent (when using detergent with a floor scrubber, use detergent only in accordance with the detergent manufacturer's instructions, appropriate dosage, and restrictions.)
- Maintenance and repair of this floor scrubber should only be carried out by properly trained personnel using suitable tools.
- Turn off the power or remove the battery when cleaning or maintaining machine.
- It is prohibited to use high-pressure water or steam equipment to clean machine.
- Do not allow water to enter electrical components.
- NOTE: It is prohibited to use this floor scrubber to clean flammable liquids, solvents, fuels, reactive metal vapours or flammable dusts.

Safety Symbols

The product may have safety warning labels attached to it, explained below. Understand the symbols on your product and their meanings. If any stickers become unreadable, unattached etc., replace them.



Flammable Material Hazard
Flammable liquids, gases, or substances etc may present. Avoid ignition sources and open flames. Danger of fire.



Read User Manual
Read and fully understand product safety warnings, operation, procedures etc before using the product.



Use Hand Protection
Wear appropriate hand protection and take due care as the product or use of the product may present hand hazards.



Carbon-Monoxide Hazard
Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.



Electrocution / Electrical Shock Hazard
High voltage or high current electricity may be present or required by the product. Take due care when handling electrical products, cables, plugs and leads. Electrical shock can be fatal.



Toxic Fumes / Dust Hazard
Using the product or by-products from use may produce fumes, smoke or particles that could be harmful if inhaled. Wear appropriate breathing protection and have adequate ventilation.



Explosive Material Hazard
Combustible liquids, gases, or substances etc may be present. Avoid ignition sources and open flames. Danger of explosion.



Cutting / Amputation Hazard
The product may have blades, edges or mechanical devices that can cause severe cut injury to fingers, limbs etc. Take due care when handling and using the product.



Crush Hazard
The product may have blades, edges or mechanical devices that can cause severe crush injury to fingers, limbs etc. Take due care when handling and using the product.



Single Operator Only
The product must be operated by a single person only. More than one person operating the product may introduce additional hazards.



Use Face Protection
Wear appropriate full-face protection and take due care as the product or use of the product may present face and eye hazards.



Use Foot Protection
Wear appropriate foot protection and take due care as the product or use of the product may present foot hazards.



Use Eye / Ear / Head Protection
Wear appropriate eye and / or ear and / or head protection and take due care as the product or use of the product may present eye, hearing, and head hazards.



Running Hazard
Do not run on or near the product as doing so may present a fall hazard.



Diving Hazard
Do not dive into the product as doing so may present a neck / head injury hazard.



Adult Supervision Required
Always supervise children and other users of a product to prevent drowning or injury.



Skin Penetration / Puncture Hazard
The product may produce pressure, emit liquids or objects that can cause severe injury to fingers, limbs, blood etc. Take due care when handling and using the product.



Hot Surface Hazard
Be aware that the product may produce high temperatures and hot surfaces that can cause burn injuries.



Flying Debris Hazard
Be aware that the product or use of the product may present hazards produced by flying debris. Wear appropriate clothing and protective devices.



Moving Parts Hazard
Be aware that the product contains or uses mechanical devices that move or rotate. Always wait for moving parts to stop fully before handling the product, adjusting, maintenance etc.

© Auch

 **Carbon-Monoxide Hazard** Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.	 **Pull Hazard** Be aware that the product contains or uses mechanical devices that can pull in objects and can cause severe injury to fingers, limbs etc. Take due care when handling and using the product.	 **Slope / Fall Injury Hazard** Be aware that using the product on sloping surfaces or in slippery conditions may present additional dangers from falls and contact with blades, moving parts, hot surfaces etc.	 **"Slam Dunk" Warning** Do NOT attempt "slam dunk" manoeuvres as this may result in severe injury due to falling, product breakage or collapse etc.
 **Electrocution / Electrical Shock Hazard - Outdoor** High voltage or high current electricity may be present or required by the product. Do NOT use in rain, damp, or wet conditions. Electrical shock can be fatal.	 **Electrocution / Electrical Shock Hazard - Disconnect** High voltage or high current electricity may be present or required by the product. Always disconnect the product from the electrical supply before handling the product, adjusting, maintenance etc.	 **Power Line Electrocution Hazard** High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal.	 **"Kick-Back" Hazard** High level of "kick-back" hazard that can cause the machine to suddenly rotate towards operator. Kick-back injury can be fatal.
 **Winch Operator Position Hazard** Do NOT stand between winch and load. Do NOT use winch to move people.	 **Winch Lift Hazard** Do NOT LIFT load vertically. Use machine to PULL only.	 **Cable Hazard** Ensure that load bearing cable is not kinked or knotted.	 **Winch Cable Hazard** Ensure that there is a minimum number of cable coils on winching mechanism.
 **Winch Hook Hazard** Carry hook to load – do NOT throw or run.	 **Flash / Blinding Hazard** Wear appropriate eye protection for welding. Direct exposure to weld arcs may cause permanent eye injury.	 **Laser Hazard** Laser may be in use – do NOT look directly at laser or allow others to.	 **Choking Hazard** Children under 8 yrs. Can choke or suffocate on small parts. Adult supervision required.

© Auch

Table of Contents

Safety **2**
Safety Symbols 4
Assembly **7**
Packing and Unpacking 7
Installation of the malish brush 7
Installation of Squeegee Blade 7
Operation **8**
Starting the Floor Scrubber 8
Indicator Lights 8
Operating Instructions for Full Sewage Tank 8
Maintenance **10**
Daily Maintenance and Upkeep 10
Monthly Maintenance and Upkeep 10
Motor Maintenance 10
Battery Maintenance 10
Machine Storage 11
Lead-Acid Battery Care and Maintenance **12**
Top 3 Battery Care Requirements 12
Troubleshooting **13**
Specifications **14**

Assembly

Packing and Unpacking

- **Packing**: The equipment is packaged in a specific way and comes with wooden pallets that are easy to load and unload by forklifts.
- **Dismantling**: (1) Tear off the wrapping film (2) Cut off the packaging bag (3) Take away the packaging cardboard (4) Take out the accessories (5) Use a slope to slide the machine off the wooden pallet.

Installation of the malish brush

1. Flip the machine backwards and lift the brush disc position at the front of the machine.
2. Place the malish brush in the center of the machine head flange.
3. **Manual installation**: Rotate the brush disc to the left and transfer it to the flange clamp.
4. **Automatic installation**: Place the brush tray in the bottom of the brush cover and align it. Open the power lock on the panel. When the power indicator light is on, press the brush button, and the brush will be automatically installed.



Installation of Squeegee Blade

1. The squeegee blade has been tested and installed before leaving the factory.
2. If installation is required, connect the squeegee assembly to the middle position at the bottom of the machine.
3. Hang the squeegee assembly and tighten it.
4. The upper, lower, front, back, the four sides of the squeegee blade can be replaced and used.

Spare parts available for purchase, scan QR code below:

Operation

WARNING! If the detergent used produces too much foam, it means that the detergent is not suitable for automatic washing. When using the floor machine, please add an appropriate amount of defoamer or replace the cleaning agent, otherwise it will burn out the suction motor.

Starting the Floor Scrubber



1. Install the squeegee and brush tray correctly and place them flat on the ground.
2. Press and hold the power switch for 3 seconds, the power indicator light will light up.
3. Press the brush disc motor switch, drain switch, and vacuum switch.
4. Adjust the water volume according to actual needs.
5. **ECO button description**: This function is in energy-saving mode. It is recommended to use it when the ground is flat and good. When turned ON, it will automatically reduce the power consumption of the machine, while ensuring good performance and saving power, extending battery life.



Indicator Lights

The power indicator light above the panel displays the battery level, it will show the voltage of battery. It must be charged when the digital number is below 21, full charging shows digital number 26.3.

SPECIAL Reminder: To maintain the normal service life of the battery, it is necessary to fully charge the battery in a timely manner after each use of the machine. Overcharging and discharging can affect the performance of the battery, so it is necessary to use a dedicated matching charger for charging.

Operating Instructions for Full Sewage Tank



1. When the sewage level in the sewage tank approaches the maximum limit, the float will rise and block the air outlet, causing the vacuum motor to malfunction and produce different noises. (At this point, the suction will not be able to extract water from the ground.)
2. Immediately turn OFF the suction motor and brush motor.
3. Twist the lid and open it.
4. Pull up the dirty water tank and release it from the machine.
5. Drain the dirty water and reassemble the tank to the machine.

If the handle becomes dislodged, you will need to remove the x4 screws that secure the control panel. Once you have done this you can pull the control panel off.



Underneath the control panel, you will see a screw. Use the included tool to tighten the screw. Once you have done this you can re-secure the screw.



© Auch

Maintenance

Daily Maintenance and Upkeep

- Remove the needle holder/brush plate and clean it with a specific cleaning agent.
- Drain the sewage tank and rinse with clean water. Check for debris in the sewage tank and remove it immediately if any. In addition, the remaining solvent in the clean water tank must also be drained.
- Lift the squeegee assembly off the ground and wipe the squeegee blade with a wet towel.
- Remove the vacuum suction inlet filter device and rinse it with clean water.
- Wipe the machine clean with a specific cleaner.
- Charge the battery.
- Check whether the edge of the squeegee blade is sharp. If it is damaged, please turn it around or replace it.

Monthly Maintenance and Upkeep

- Check that the top of the battery is clean to prevent corrosion.
- Check whether the battery cable is loose or corroded.
- Check the sealing of the sewage tank cover and replace it if it is damaged.
- Lubricate all lubricated parts and shafts with specific lubricant.
- Check whether machine fasteners are loose.
- Check the water tank for leaks.

Motor Maintenance

- Motor maintenance should include regular dust removal and lubrication, check for loose wiring and insulation protection.
- The motor carbon brushes should be inspected after every 250 hours of use. If the carbon brushes are severely worn, replace the motor.

Battery Maintenance

Please follow the battery charging chapter in each manufacturer's operating manual for maintenance.

The top of the battery and the electrodes must be anti-corrosive. Soda water can be used to prevent corrosion, but this solution must not enter the battery.

Use a brush dipped in soda water to wipe the battery and battery cables.

Regularly check whether the battery cable is worn and whether the contacts are loose and replace it if necessary.

© Auch

Machine Storage

- Store in a dry places indoors.
- Store upright.
- Lift the brush tray off the ground.
- Lift the wiper assembly off the ground.
- If the storage location is extremely cold, you need to keep the machine completely dry to avoid damage caused by low temperatures.
- Drain the recovery and solution tanks.

Lead-Acid Battery Care and Maintenance

Top 3 Battery Care Requirements

1. **Charge battery before first use**. The battery may arrive with some charge, regardless of this the battery must be charged for 6-8 hours on the initial charge and 6-8 hours for each subsequent charge.
2. **Charge battery immediately when it is depleted.** Do not store a depleted battery. This will permanently impact the life of the battery. If the battery is going to be stored for a period of time, fully charge the battery before storing.
3. **Disconnect battery when not in use**. To prolong the life of a battery, disconnect it from the unit when not in use. Disconnect chargers from the battery once charged.

To ensure the battery maintains optimum performance, follow the guidelines outlined below.

- For best results, charge batteries in temperatures between 10°C and 30°C
- When battery is charged, disconnect the charger from the power supply and remove the battery from the charger.
- Inspect the terminals, screws, clamps and cables for breakage, damage, or loose connections. These should be clean, tight, and free of corrosion.
- Use only with the battery charger specified by the manufacturer.
- Ensure that the battery charger electrical cord is not subjected to damage or stress. Do not operate the battery charger if it has a damaged electrical cord or plug.
- Do not use the charger in wet areas or expose it to rain or water.
- Keep the battery clean, dry, free of dirt and grime. A dirty battery can discharge across the grime on top of the battery casing.
- Apply a thin coating of high temperature grease to posts and cable connections for added protection.
- Inspect the battery case for obvious signs of physical damage or warpage. This usually indicates the battery has been overheated or has been overcharged.
- Batteries can explode in the presence of an ignition source, such as a pilot light. To reduce the risk of serious personal injury, never use any cordless product in the presence of open flame. Exploding batteries can propel debris and chemicals.
- Do not open the battery – danger of short-circuiting and/or explosion.
- Do not attempt to destroy or disassemble the battery pack or remove any of its components.
- Do not touch the battery terminals with metal objects and/or body parts as short-circuit and/or personal injury may result.
- Explosion hazard – protect the battery against heat, for example, direct sunlight and fire. Do not store batteries in vehicles or locations subject to heat.
- Explosion hazard – do not open and/or short-circuit the battery.
- Poison hazard – battery leakage (liquid ejection). Under extreme conditions, liquid may be ejected from the battery – avoid contact. If contact accidentally occurs, immediately seek medical attention, and flush with water. If liquid contacts eyes, immediately seek medical attention, flush with clean water for at least 10 minutes. Liquid ejected from the battery may cause irritation or burns.
- Dispose of non-serviceable batteries in an environmentally responsible manner and according to local regulations.

Failure to adhere to the requirements above may result in the battery becoming inoperative or battery life being reduced. In extreme cases or abuse, battery overheating, or fire may result.

Troubleshooting

Malfunction	Cause analysis	Solution
Machine cannot run	Power switch button malfunction	Replace button panel
	Low battery level	Charge battery
	Battery damage	Replace battery
	Battery wiring is loose or aging	Tighten or replace wiring
	Motherboard damage	Replace
	Line fault	Replace
The brush disc motor cannot operate	Brush disc switch malfunction	Replace button panel
	The brush disc motor or its circuit were damaged	Replace
	The carbon brush of the brush disc motor is severely worn	Replace
	Damaged motherboard or poor circuit contact	Replace
The suction motor cannot operate	Vacuum motor switch malfunction	Replace button panel
	The carbon brush of the vacuum motor is severely worn	Replace
	Damaged vacuum motor or circuit	Replace
	The motherboard or its wiring were damaged	Replace
Small or no water output from the machine	Water valve opened; too small or closed	Adjust water valve
	The position of the brush disc outlet pipe is blocked	Use thin wire to clear the pipe
	Blocked solenoid valve	Disassemble the solenoid valve and clean it
The suction power is low, or the cleaning is not clean	The sewage tank is full	Drain sewage
	The cover of the sewage tank is not tightly closed	Check if it is covered properly
	The suction pipe is blocked	Unclog pipes
	Wear of squeegee blade	Transfer or replace
	The height position of the squeegee blade is incorrect	Adjust the height
	The suction pipe is not tightly inserted or detached	Adjust
	Damaged suction pipe	Replace
	The sealing strip of the sewage tank cover is missing or damaged	Replace the sealing strip
	Damaged vacuum motor	Replace

Malfunction	Cause analysis	Solution
Short usage time	Low battery level	Charge battery
	Battery damage	Replace
	Battery should be used correctly	See Battery Use and Maintenance
	Charger damaged	Replace

Specifications

Rated Power	400W (Cleaning disc motor), 360W (Water suction motor)
Brush Width	360mm
Squeegee Width	420mm
Solution/Recovery Tank (L)	13/15
Battery Capacity	2 x 24V/32Ah
Run Time	1.5-2 hr
Working Capacity	1350㎡/h
Brush Pressure	15-17kg
Disc Speed	180RPM

Note: Minimal Assembly Required

Some experts believe that the incorrect or prolonged use of almost any product may cause serious injury or death. To help reduce your risk of serious injury or death, refer to the information below. For more information, see www.datastreamserver.com/safety

- Consult all documentation, packaging, and product labelling before use. Note that some products feature documentation available online. It is recommended to print and retain the documentation.
- Before each use, check the product for loose/broken/damaged/missing parts, wear, or leaks (if applicable). Never use a product with loose/broken/damaged/missing parts, wear, or leaks.
- Products must be inspected and serviced (if applicable) by a qualified technician every 6 months. This is based on average residential use by persons of average size and strength, and on a property of average metropolitan size. Use beyond these recommendations may require more frequent inspections/servicing.
- Ensure that all users of the product have completed a suitable industry recognised training course before being allowed access to the product.
- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or description of application. Be sure to attain third-party approval from a qualified specialist for your application before use, regardless of any assurances from the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (for example, automobile, computer, toaster), there is the possibility of technical issues that may require the repair or replacement of parts, or the product itself. If the possibility of such failure and the associated time it may take to rectify could in any way inconvenience the user, business, or employee, or financially affect the user, business, or employee, then the product is not suitable for your requirements. This product is not intended for use where incorrect operation or a failure of any kind, including but not limited to, a condition requiring product return, replacement, parts replacement, or service by a technician may cause financial loss, loss of employee time or an inconvenience requiring compensation.
- If this product has been purchased in error when considering the information presented here, contact the retailer directly for details of their returns policy, if required.

© Auch. All rights reserved. No part of this document, including descriptive content, concepts, ideas, diagrams, or images may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, scanning, or recording, or any information storage and retrieval system, without express permission or consent from the publisher.